





Pick




CF3441HCR
Monomando Lavabo Alto "PICK" Cromo



CF3441CR
Monomando Lavabo "PICK" Cromo



CF3431CR
Batería de pared "PICK" Cromo



CONTIENE DESAGUE CLICKER CON TAPON REDONDO

